







# Power tools

- ◆ Do not use as a battering ram
- ◆ Do not manhandle tool while spreading
- ◆ Keep hands clear of obstructions
- ◆ Stand away from door, do not lean against
- ◆ Know the capabilities of your tool

# Relocating the Dashboard



# Relocating the Dash

- ◆ Steering wheels break free if impacted by driver
  - Energy absorbing
- ◆ Minimal support from A-post to A-post
- ◆ Lots of plastic

